



NO	HHAW PARTS NO	Q' TY	PARTS NAME
	RAF-50RPA		
1	HWRAF-50NX2 A01	1	CABINET
2	HWRAF-50NX2 A02	1	PWM-MOTOR
3	HWRAF-50NX2 A03	1	TANGENTIAL AIR FLOW FAN
4	HWRAF-50NX2 A04	1	FAN SUPPORT ASSEMBLY
5	HWRAF-50NX2 A05	1	FAN COVER
6	HWRAF-50NX2 A06	1	FAN MORTOR SUPPORT
7	HWRAF-50NX2 A07	1	#F-PANELAS
8	HWRAF-50NX2 A08	1	DEFLECT
9	HWRAF-50NX2 A09	1	EVAPORATOR ASSEMBLY
	HWRAF-25NX2 A01	1	EVAPORATOR ASSEMBLY
10	HWRAF-50NX2 A10	1	P-COVER-L
11	HWRAF-50NX2 A11	1	P-COVER-R
12	HWRAF-25FPA A01	1	THERMISTOR ASSEMBLY
13	RAS-25DVX002	1	SPRING
14	HWRAF-25NX2 A02	1	DRAIN PAN
	HWRAF-50NX2 A14	1	DRAIN PAN
15	HWRAF-50NX2 A15	1	#L-DEF-AS
16	HWRAF-50NX2 A16	1	#R-DEF-AS
17	HWRAF-50NX2 A17	1	GUARD
18	HWRAF-50NX2 A18	1	AUTO SWEEP MOTOR
19	HWRAF-50NX2 A19	1	BOARD
20	HWRAF-50NXA1 A01	1	FRONT COVER ASSEMBLY
21	HWRAF-50NX2 A21	2	FILTER
22	HWRAF-25RPA A02	1	REMOTE CONTROL ASSEMBLY
23	HWRAF-50NX2 A22	1	SCREW ASSEMBLY
24	HWRAF-50NX2 A23	1	#ELE-PLATE
25	HWRAF-50NX2 A24	1	ELE-COV-1
26	HWRAF-50NX2 A25	1	ELE-COV-2
27	HWRAF-50NX2 A26	1	TERM-COV-1
28	HWRAF-50NX2 A27	1	TERM-COV-2
29	HWRAF-25RPA A03	1	M-PWB-SUP
30	HWRAF-50NX2 A29	1	BAND
31	HWRAF-50NX2 A30	1	2PTERMINAL
32	HWRAF-25RPA A04	1	#2PCORD-AS
33	HWRAF-50NX2 A32	1	IRR-SUP
34	HWRAF-50NX2 A33	1	IRR-COV1
35	HWRAF-50NX2 A34	1	LENS-COVER
36	HWRAF-25RPA A05	1	#9PCORD-AS
37	HWRAF-50RPA A01	1	P. W. B. (MAIN)
	HWRAF-35RPA A01	1	P. W. B. (MAIN)
	HWRAF-25RPA A06	1	P. W. B. (MAIN)
38	HWRAF-50NX2 A38	1	BOARD
39	HWRAF-50NX2 A39	1	DRAIN-HOSE