



NO	HHAW PARTS NO			Q' TY/UNIT	PARTS NAME
	RAK-18PSB	RAK-25PSB	RAK-35PSB		
1		HWRAK-18PSA A01		1	CABINET
2		HWRAK-18PSA A02		1	COVER (LOWER) (LEFT)
3		HWRAK-18PSA A03		1	COVER (LOWER) (RIGHT)
4		HWRAK-18PSA A04		1	COVER (REAR) (RIGHT)
5		HWRAS-SX10HAK A05		1	MOUNTING PLATE
6		HWRAS-SX10HAK A06		1	TANGENTIAL AIR FLOW FAN
7		HWRAS-SX10HAK A07		1	FAN MOTOR
8		HWRAS-SX10HAK A08		1	FAN SUPPORT ASSEMBLY
9		HWRAK-18PSA A05		1	PIPE SET
10		HWRAK-18PSA A06		1	2-UNION
11		HWRAK-18PSA A07		1	3-UNION
12		HWRAK-18PSA A08		1	FO-PIPE (HEAT INSULATOR)
13		HWRAK-18PSA A09		1	HEAT EXCHANGER ASSEMBLY
14		HWRAS-SX10HAK A14		1	FAN COVER
15		HWRAS-SX10HAK A15		1	FAN MOTOR SUPPORT
16		HWRAK-18PSA A10		1	THERMISTOR ASSEMBLY
17		HWRAS-SX10HAK A19		1	BULB SUPPORT (THERMISTOR)
18		HWRAK-18PSA A11		1	PIPE-COVER
19	HWRAK-18PSB A01	HWRAK-25PSB A01	HWRAK-35PSB A01	1	P.W.B. (CONTROL)
20		HWRAS-SX10HAK A23		1	ELECTRIC PARTS PLATE
21		HWRAS-SX10HAK A24		1	P.W.B. (CONTROL) SUPPORT
22		HWRAS-SX10HAK A25		1	ELECTRIC PARTS COVER (LEFT)
23		HWRAS-SX10HAK A26		1	ELECTRIC PARTS COVER (RIGHT)
24		HWRAK-18PSB A02		1	TERMINAL BOARD (3P)
25	HWRAK-18PSB A03	HWRAK-25PSB A02	HWRAK-35PSB A02	1	P.W.B. (CONTROL) ELECTRIC ASSEMBLY
26		HWRAS-SX10HAK A29		1	DRAIN CAP
27		HWRAS-SX10HAK A30		1	HEAT INSULATOR (DRAIN CAP)
28		HWRAS-SX10HAK A31		1	STEPPING MOTOR (HORIZONTAL AIR DEFLECTOR) (LEFT)
29		HWRAS-SX10HAK A32		1	STEPPING MOTOR (HORIZONTAL AIR DEFLECTOR) (RIGHT)
30		HWRAK-18PSA A15		1	HORIZONTAL AIR DEFLECTOR ASSEMBLY
31		HWRAS-SX10HAK A34		1	HORIZONTAL AIR DEFLECTOR SUPPORT
32		HWRAS-SX10HAK A35		1	STEPPING MOTOR (VERTICAL AIR DEFLECTOR)
33		HWRAS-SX10HAK A36		1	DRAIN HOSE
34		HWRAK-18PSA A16		1	ION MIST UNIT
35		HWRAS-SX10HAK A39		1	FC-GUIDE
36		HWRAS-SX10HAK A40		1	COVER (P.W.B INDICATION)
37		HWRAK-18PSB A04		1	P.W.B.(INDICATION)
38		HWRAS-25YH4 923		1	CORD (P.W.B INDICATION)
39		HWRAK-18PSB A05		1	DRAIN PAN ASSEMBLY
40		HWRAK-18PSA A20		1	FRONT PANEL ASSEMBLY
41		HWRAS-SX10HAK A45		1	INFRARED DYNAMIC AIR DEFLECTION SENSOR
42		HWRAS-SX10HAK A46		1	DYNAMIC SENSOR SUPPORT
43		HWRAK-18PSA A21		1	DYNAMIC SENSOR COVER
44		HWRAK-18PSB A06		1	FRONT COVER ASSEMBLY
45		HWRAS-SX10HAK A49		2	AIR CLEANING MESH BOX
46		HWRAS-SX10HAK A50		1	TERMINAL COVER ASSEMBLY
47		HWRAK-18PSA A23		2	SCREW CAP
48		HWRAK-18PSA A24		1	DUST BOX
49		HWRAK-18PSB A07		1	REMOTE CONTROLLER
50		HWRAS-SX10HAK A54		2	FILTER LOCKER
51		HWRAS-SX10HAK A55		2	STAINLESS MESH FILTER
52		HWRAS-SX10HAK A56		1	DUST CATCHER
53		HWRAS-SX10HAK A57		1	WIPER (BRUSH)
54		HWRAS-SX10HAK A58		1	WIPER COVER
55		HWRAS-SX10HAK A59		1	WIPER ASSEMBLY
56		HWRAS-SX10HAK A60		1	SWITCH (THE RIGHT OF CLEANING UNIT)
57		HWRAS-SX10HAK A61		1	CORD (2P) (FOR CLEANING UNIT SWITCH)
58		HWRAS-SX10HAK A62		1	AUTO SWEEP MOTOR
59		HWRAS-SX10HAK A63		1	CORD (4P) (FOR AUTO SWEEP MOTOR)
60		HWRAK-18PSA A26		1	P.W.B. (MIST SENSOR)
61		HWRAS-SX10HAK A65		1	SB-COVER (FOR MIST SENSOR)
62		HWRAS-SX10HAK A66		1	CORD (4P) (FOR MIST SENSOR)
63		HWRAS-SX10HAK A67		1	FILTER CLEANING UNIT
64		HWRAS-SX10HAK A68		1	HEAT INSULATING MATERIAL (FOR REFRIGERATING PIPE SET WHEN INSTALLING)
65		HWRAK-18PPB 902		1	RE-HOLDER