



NO.	PART NO.	Q'TY / UNIT	PARTS NAME
2	PMRAC-60YH7 S01	2	COMPRESSOR
3	KPNT1 001	6	PUSH NUT
4	RAC-2226HV 805	6	COMPRESSOR RUBBER
5	PMRAC-50NH4 S02	2	CONDENSER
	PMRAM-130QH5 S15	1	CONDENSER ASSY (OPTIONAL)
6	PMRAC-S18CPA S02	2	REVERSING VALVE
7	PMRAM-90NP5B S03	2	EXPANSION VALVE COIL (W)
8	PMRAM-90NP5B S04	2	EXPANSION VALVE COIL (R)
9	PMRAM-90NP5B S05	2	EXPANSION VALVE COIL (B)
10	PMRAM-65QH4 S15	6	VALVE (2S)
11	PMRAM-65QH4 S16	6	VALVE (3S)
12	PMRAC-40CNH2 S14	2	THERMISTOR(OH)
13	PMRAC-25NH4 S09	2	THERMISTOR SUPPORT (OH)
14	PMRAC-25NH4 910	2	OLR COVER
15	PMRAC-VX13CET S04	1	TERMINAL BOARD (3P)
16	PMRAM-90NP5B S09	2	MG-COIL (REVERSING VALVE)
17	PMRAM-90QH5 S01	7	2P TERMINAL FOR C-D LINE
18	PMRAC-63CA1 S02	1	TERMINAL BOARD (2P)
19	PMRAC-40CNH2 S17	2	PROPELLER FAN
20	PMRAC-40CNH2 S18	2	SUPPORT (FAN MOTOR)
21	PMRAC-VX13CET S02	2	FAN MOTOR
22	PMRAM-130QH5 903	1	CABINET
23	PMRAM-130QH5 904	2	NET
24	PMRAM-130QH5 908	1	TOP COVER
25	PMRAM-110NP6B S03	1	SIDE PLATE R
27	PMRAC-51CHA1 S07	2	D-GRILL-AS
29	PMRAM-33NP2B S05	6	ELECTRICAL EXPANSION VALVE
30	PMRAM-65QH4 917	2	STRAINER (ST-PIPE-AS 1)
31	PMRAM-65QH4 918	2	STRAINER (ST-PIPE-AS 2)
32	PMRAM-65QH4 919	2	STRAINER (ST-PIPE-AS 3)
33	PMRAM-53NP2A S05	2	STRAINER (CO-PIPE-AS)
34	PMRAM-65QH4 S10	1	THERMISTOR (OUTSIDE TEMPERATURE)
35	PMRAM-110NP6B S01	2	P.W.B. (MAIN)
36	PMRAM-110NP6B S02	2	P.W.B. (INVERTER)
37	PMRAC-X18CD S04	2	REACTOR
38	PMRAM-110NP6B S04	2	SV-COVER
40	PMRAM-55QH4 S05	2	THERMISTOR (DEFROST)
41	PMRAM-72QH5 S20	2	THERMISTOR SUPPORT
42	PMRAM-53NP3B S04	2	THERMISTOR-V (W)
43	PMRAM-53NP3B S03	2	THERMISTOR-V (R)