



NO	JCH-WH PARTS NO	Q' TY/UNIT	PARTS NAME
1	HWRAC-35WPC A01	1	BASE
2	HWRAC-18WED A02	1	COMPRESSOR
3	HWRAC-25YH4 A04	3	PUSH NUT
4	HWRAC-18WPD A01	1	CONDENSER
5	HWRAC-18WPD A02	1	REVERSING VALVE
6	HWRAC-50WEA A06	1	2S-VALVE
7	HWRAC-10GH5 A03	1	3S-VALVE
8	HWRAC-SX10HAK A09	1	SOUND PROOF COVER ASSEMBLY
9	HWRAC-18WPD A03	1	ELECTRIC EXPANSION VALVE
10	HWRAC-25WXA A04	1	SOUND PROOF COVER ASSEMBLY
11	HWRAC-18WEB A07	1	O. L. R COVER
12	HWRAC-18WPD A04	1	SOUND PROOF COVER ASSEMBLY
13	HWRAC-18WED A06	1	CONNECTING CORD (COMP)
14	HWRAC-E10H2 A09	1	THERMISTOR (DEFROST)
15	HWRAC-25WX8 A02	1	THERMISTOR SUPPORT
16	HWRAC-25WXD A09	1	COIL (REVERSING VALVE)
17	HWRAC-50WED A07	1	COIL (EXPANSION VALVE)
18	HWRAC-18WPD A05	1	PARTITION
19	HWRAC-18WED A07	1	REACTOR 1
20	HWRAC-35WPB A05	1	SOUND PROOF COVER ASS' Y
21	HWRAC-14EH4 A08	1	FAN MOTOR SUPPORT
22	HWRAC-50WED A10	1	FAN MOTOR
23	HWRAC-18WED A09	1	PROPELLER FAN
24	HWRAC-50NX2 A25	1	NUT (PROPELLER. FAN)
25	HWRAC-25YH4 A25	1	SIDE COVER (L)
26	HWRAC-25YH4 A26	1	HANDLE
27	HWRAC-35WPC A08	1	FRONT COVER
28	HWRAC-E14H3 909	1	DISCHARGE GRILL
29	HWRAC-18WPD A06	1	SOUND PROOF COVER ASS' Y
30	HWRAC-18WPD A07	1	SOUND PROOF COVER ASS' Y
31	HWRAC-35WPC A09	1	ELECTRIC PARTS PLATE
32	HWRAC-18WPD A08	1	TERMINAL COVER
33	HWRAC-18WPD A09	1	FUSE (15A)
34	HWRAC-50WED A16	1	TERMINAL BOARD (5P)
35	HWRAC-25YHA5 A21	1	HEAT SINK (REGURATOR1)
36	HWRAC-18WPD A10	1	P. W. B (CONTROL)
	HWRAC-25WPD A01	1	P. W. B (CONTROL)
	HWRAC-35WPD A01	1	P. W. B (CONTROL)
37	HWRAC-35WPC A11	1	SUPPORT (P. W. B CONTROL)
38	HWRAC-18WPD A11	1	SOUND PROOF COVER ASS' Y
39	HWRAC-18WPD A12	1	SOUND PROOF COVER ASS' Y
40	HWRAC-25YH4 A48	1	BUSH ASSEMBLY
41	HWRAC-18WPD A13	1	ELECTRIC PARTS COVER
42	HWRAC-14EH4 A16	1	TOP COVER
43	HWRAC-18WPD A14	1	SERVICE VALVE COVER
44	HWRAC-E14H3 915	1	SIDE COVER (R)
45	HWRAC-14EH4 A15	1	COVER (OUT DOOR THERMISTOR)
46	HWRAC-E14H3 914	1	THERMISTOR (OUTDOOR TEMPERATURE)
47	HWRAC-25YH4 A50	1	DRAIN PIPE
48	HWRAC-25YH4 A49	1	BUSH
49	HWRAC-25WXD A11	2	FUSE (3. 15A)